Super Gameboy notes

2010-12-27, d4s (matt@dforce3000.de)

Scope:

This document does not give a full overview of the Super Gameboy hardware and functions. Instead, it just covers the stuff that's not available elsewhere. What I found out is based on prior research by Byuu, his Bsnes sourcecode and the Super Gameboy boot ROM dumped & reverse-engineered by FPGABoy and Frode van der Meeren.

Interface:

The Super Gameboy contains a complete Gameboy sans display, buttons etc.

It is interfaced to the SNES by a chip called 1CD2-R.

There are two known versions of this chip, identifiable by their chip package designation and by reading out the version register.

The only known functional difference between them is the amount of address lines they use to decode register accesses.

I will just refer to them by their version number from now on, \$21 and \$61, respectively.

Registers:

The 1CD2-R doesn't use all 24 address lines to decode register accesses, which means registers are not only accessible at one specific address, but mirrored across a certain memory range:

Control registers:

- -banks \$00-\$3f and \$80-\$bf
- -offset \$6000-\$67ff

Command port:

- -banks \$00-\$3f and \$80-\$bf
- -offset \$7000-\$77ff
- -When starting up, the GB CPU bootstrap code uploads 6 commands to the SGB containing data of the inserted Gameboy cartridge, range \$0104-\$014f(Header of Gameboy ROM and Nintendo logo).
- -Each command is preceded by an identifier (\$f1-\$fb) and a 1 byte checksum of all values in the corresponding block added up.
- -This is what the blocks look like from the perspective of the SNES CPU:

\$f1 chsum [\$0104] [\$0105] [\$0106] [\$0107] [\$0108] [\$0109] [\$010A] [\$010B] [\$010C] [\$010D] [\$010E] [\$010F] [\$0110] [\$0111] \$f3 chsum [\$0112] [\$0113] [\$0114] [\$0115] [\$0116] [\$0117] [\$0118] [\$0119] [\$011A] [\$011B] [\$011B] [\$011C] [\$011D] [\$011D] [\$011F] \$f5 chsum [\$0120] [\$0121] [\$0122] [\$0123] [\$0124] [\$0125] [\$0126] [\$0127] [\$0128] [\$0129] [\$0124] [\$012B] [\$012B] [\$012C] [\$012D] \$f7 chsum [\$012E] [\$012F] [\$0130] [\$0131] [\$0132] [\$0133] [\$0134] [\$0135] [\$0136] [\$0137] [\$0138] [\$0138] [\$0139] [\$013A] [\$013B] \$f9 chsum [\$013C] [\$013D] [\$013E] [\$013F] [\$0140] [\$0141] [\$0142] [\$0143] [\$0144] [\$0145] [\$0146] [\$0147] [\$0148] [\$0149] \$fb chsum [\$014A] [\$014B] [\$014C] [\$014D] [\$014E] [\$014F] 0 0 0 0 0 0

VRAM port:

- -banks \$00-\$3f and \$80-\$bf
- -offset \$7800-\$7fff

For each register, the following information is listed:

Name (typical access address)

access: Is register readable/writable?

ICD2-R address decoding table:

Lower address lines used by both ICD2-R versions for decoding register accesses.

Applicable values are:

- -0: Address line must be low
- -1: Address line must be high
- -x: don't care

comment

SGB_LY_COUNTER (\$6000)

access: Read

ICD2-R address decoding table:

Version	A0	A1	<i>A2</i>	<i>A3</i>	A4-A10
\$21	X	0	X	0	X
\$61	0	0	0	0	X

comment:

Returns current scanline of Gameboy rendering hardware.

SGB_VRAM_UNKNOWN (\$6001)

access: Write

ICD2-R address decoding table:

Version	A0	A1	<i>A2</i>	A3	A4-A10
\$21	1	0	0	0	X
\$61	1	0	0	0	X

comment:

Exact purpose unknown, probably related to VRAM source.

SGB_CMD_READY (\$6002)

access: Read

ICD2-R address decoding table:

Version	A0	A1	<i>A2</i>	A3	A4-A10
\$21	X	1	X	0	X
\$61	0	1	0	0	X

comment:

Reads \$01 if one or more commands have been completely stored in command port. Reads \$00 if all commands have been read by the SNES CPU.

SGB CONTROL (\$6003)

access: Write

ICD2-R address decoding table:

Version	A0	A1	A2	A3	A4-A10
\$21	1	1	0	0	X
\$61	1	1	0	0	X

comment:

Main control register. Controls Gameboy CPU reset, Gameboy CPU clock speed, 1/2/4 player mode.

bit7:

- -clearing this bit resets & halts Gameboy CPU, clears SGB_CMD_READY to \$00, clears SGB_LY_COUNTER to \$00.
- -setting this bit starts Gameboy CPU if it was in halt state.

 Setting this bit after it has been set already does not reset Gameboy CPU.

 -default value is clear/halted.

bit5:

-enable 4 player mode if set

bit4:

-enable 2 player mode if set

bits0,1:

- -select Gameboy CPU clock divider.
- -The ~21Mhz master clock of the SNES is divided by four different values according to the setting of these bits.
- -hi designates for how many master clock cycles the GB CPU clock will stay high during each cycle.
- -lo designates for how many master clock cycles the GB CPU clock will stay low during each cycle.
- *-divider* is the number of master clock cycles one GB CPU clock cycle will take.
- *-DMG CPU speed* is a rough approximation of the resulting clock speed.

bit0	bit1	hi	lo	divid	ler DMG CPU speed
0	0	2	2	/4	~5.35mhz (results in graphical glitches)
1	0	3	2	/5	~4.3mhz (normal operation)
0	1	4	3	/7	~3.05mhz
1	1	5	4	/9	~2.37mhz

SGB_JOYPAD_1 (\$6004)

access: Write

ICD2-R address decoding table:

Version	A0	A1	<i>A2</i>	<i>A3</i>	A4-A10
\$21	0	0	1	0	X
\$61	0	0	1	0	X

comment:

SNES writes joypad presses here.

SGB_JOYPAD_2 (\$6005)

access: Write

ICD2-R address decoding table:

Version	A0	A1	<i>A2</i>	<i>A3</i>	A4-A10
\$21	1	0	1	0	X
\$61	1	0	1	0	X

comment:

SNES writes joypad presses here.

SGB_JOYPAD_3 (\$6006)

access: Write

ICD2-R address decoding table:

Version	A0	A1	A2	A3	A4-A10
\$21	0	1	1	0	X
\$61	0	1	1	0	X

comment:

SNES writes joypad presses here.

SGB_JOYPAD_4 (\$6007)

access: Write

ICD2-R adress decoding table:

Version	A0	A1	A2	A3	A4-A10
\$21	1	1	1	0	X
\$61	1	1	1	0	X

comment:

SNES writes joypad presses here.

SGB_VERSION (\$600f)

access: Read

ICD2-R address decoding table:

Version	A0	A1	<i>A2</i>	<i>A3</i>	A4-A10
\$21	X	X	X	1	X
\$61	1	1	1	1	X

comment:

Appears to be version register of ICD2-R. Currently known values are:

-\$21: marked *ICD2-R* on chip package

-\$61: marked ICD2-R [stylized R(probably Ricoh logo)] on chip package

Misc notes:

-The Super Gameboy Commander is a joypad developed and produced by Hori. Hori were also partly responsible for the design of the Super Gameboy(according to its credits roll). This joypad exploits what appears to be debugging features present in the Super Gameboy software that change the Gameboy clock speed and mute/unmute sound output.

SGB cheats (work with every known Super Gameboy software revision known so far):

-toggle DMG speed normal/slow/very slow:

Press shoulder buttons *l,r,r,l,l,r* during gameplay. This has to be entered extremely fast in order to work. Used by Hori Super Gameboy Commander joypad.

-toggle DMG speed fast/normal/slow/very slow:


Hold directional pad up while powering on SNES, then press shoulder buttons *l,r,r,l,l,r* during gameplay. This has to be entered extremely fast in order to work. Used by Hori Super Gameboy Commander joypad. Fast mode prone to produce graphical glitches.

-mute/unmute SGB sound:

Press shoulder buttons *r,l,l,r,r,l* during gameplay. This has to be entered extremely fast in order to work. Used by Hori Super Gameboy Commander joypad.

Appendix:





SNES master clock:


DMG CPU clock:


SNES master clock:

DMG CPU clock:

SNES master clock:

DMG CPU clock:






ICD2-R \$21 memory map, using Ultra16 memory monitor:



ICD2-R \$61 memory map, using Ultra16 memory monitor:



SGBコマンダー 取扱説明書

このたびはホリ電機のSGBコマンダーをお買い上げいただきまして、誠にありがとうございました。 ご使用前に、必ずこの「取扱説明書」をよくお読みいただき、正しい使用法でご愛用ください。

機能説明


この製品SGBコマンダーでは、スーパーゲームボーイ使用時、こ のコントローラーの特殊機能として下記のものがあります。

- ・「スピード」 ゲームスピードの切り替え
- ·「ミュート」 (音の ON/OFF)

以上の機能は、スーパーファミコンの1プレイヤー側に差している ときだけ使用できます。

2プレイヤー側では「スピード」と「ミュート」は使用することが 出来ませんのでご注意ください。

各部のなまえ



スライドスイッチの説明

スーパーゲームボーイ スーパーファミコン

SGB SFC 1

● 「SGB」モードではスーパーゲームボーイ専用のボタン設定

スーパーファミコン用のソフトを「SGB」のモードで使用され ると、誤動作の原因となるのでスーパーファミコン用ソフトは 「SFC」モードでご使用ください。

☆注意事項 かならずお読みください。

スーパーゲームボーイをSGBコマンダーで使うに当って以下の点に御注意 ください。

「SGB」モードで使用するときは、スーパーゲームボーイ本体 のボタン配置はBタイプでご使用下さい。

(AタイプではBボタンが使用できなくなります)

「スーパーゲームボーイのマニュアルを読んでください。」

・スーパーファミコン用としてSGBコマンダーを使用されると きは、スライドスイッチを「SFC」でお使いください。

(「SGB」で使用されると誤動作の原因になります)

- ・スーパーゲームボーイで、SGBコマンダーの機能を使用する さい、2プレイヤー側にコントローラーをセットした状態です と「スピード」と「ミュート」の機能は使用できませんのでご 了承ください。
- SGBコマンダーの機能でゲームスピードをかえられる「スピ ード」でゲームスピードを速くしますと、画面にノイズがでま すが、故障ではありませんので安心してお使いください。

の他、スーパーゲームボーイの操作に関しては、スーパーゲームボーイの

取扱説明書をお読みください。

スーパーケームボーイ・スーパーファミコン・は任天堂の商標です。 定格 DC 5V 15m A

●各ボタンの機能説明

(スライドスイッチが SGBの時の説明です。)

☆WINDOW-R (ウィンドウ)

スーパーゲームボーイのウィンドウを開けたり閉めたりす ることが出来ます。

☆COLOR-X(カラー)

スーパーゲームボーイで色をかえた場合の色と もとの色 (電源投入時から設定されている色)とを、入れ換えること が出来ます。

☆SPEED-Y(スピード)

*ソフトによってはスピード切り替え 出来ないものが有ります。

3段階にゲームスピードを切り替えられます。

スピード切り替えの順番は。

NORMAL → SUPER SLOW → SLOW-

の順番です、「SLOW」後は「NORMAL」に戻ります。 「SUPER SLOW」は「NORMAL」よりゲームスピードが 約45%遅くなります。

「SLOW」は「NORMAL」よりゲームスピードが約30% 遅くなります。


電源投入時及び、コントローラーをスーパーファミコンに 差し込んだときは「NORMAL」スピードになってます。

通常スピードは3段階切り替えですが、十字キーの上を押しなが らコントローラーを差し直すか、十字キーの上を押しながらスー パーファミコンの電源を入れ直してください。スピードが4段階 切り替え出来るようになります。(「DASH」モードが追加され ます。) ノイズが気になるかたは、3段階モードでお楽しみください。

NORMAL → DASH → SUPER SLOW → SLOW-

の順番です、「SLOW」後は「NORMAL」に戻ります。 「DASH」は「NORMAL」よりゲームスピードが約25% 速くなります。

e 1864 HORI ELECTRIC CO., LTD. 「DASH」のときにノイズがでます



- 5-8000 テレビ画面ノイズ例使いください。

が、スーパーファミコン・テレ ビ・スーパーゲームボーイの故障 ではありませんので、安心してお

☆MUTE-L(ミュート)

音の ON/OFF がボタンーつで出来ます。

(スライドスイッチがSFCの時の説明です。)

通常のスーパーファミコン用コントローラーとして使用で きます。ボタン配置は、

MUTE-LはLボタン、SPEED-YはYボタン、 COLOR-XはXボタン、WINDOW-RはRボタン、 SELECT·START·A·Bボタンは変わりません。





ホリ電機株式会社 : 〒226 横浜市緑区佐江戸町640 : 045 (933) 9611(代)